

K4 high pressure washers

K 4.86M



makes a difference

K4 – Deluxe class.

Standard accessories:

- Trigger gun
- High-pressure hose 6 m
- Vario-power spray lance
- Dirt Blaster
- Detergent suction hose With filter
- Detergent tank

Order no.: 1.636-423.0



Technical data

Pressure (bar/MPa)	20-max. 130/2-max. 13
Water flow rate (l/h)	max. 440
Max. water feed temperature (°C)	up to 40
Connected load (kW)	1.9
Weight without access. (kg)	13.4
Dimensions (L x W x H) (mm)	310x275x815
Detergent tank (l)	0.7

K4 high pressure washers

K 4.86M



makes a difference

Details

Description

Where greater demands are made on the unit and its cleaning performance. For heavy soiling and frequent use. Easy to operate and highly functional.

Application

For regular cleaning operations around the house, for medium-sized areas and for washing vehicles.

Optional Accessories

Accessory kits

Window and conservatory cleaning kit

Kit for cleaning and drying outdoor windows and conservatories. Consists of soft large surface brush, vario joint and three-stage spray lance extension for cleaning high, difficult-to-reach areas without a ladder. Comes with a wiper for drying glass surfaces. Wiper connects to Kärcher trigger gun and spray lance extensions, with low-pressure fan jet nozzle for applying detergent and clear-rinsing windows. Suitable for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class. Available in an appealing gift package.



Order no. 2.640-771.0

Motorbike cleaning kit

Kit for cleaning motorbikes, scooters, mopeds and bicycles. Short two-way spray lance, wheel washing brush and 500 ml bike cleaner. Short two-way spray lance with low-pressure fan jet and soft high-pressure fan jet enables gentle but thorough cleaning without damaging sensitive parts and simplifies cleaning of difficult-to-reach areas. Suitable for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class. Using the Kärcher garden hose adapter wash brushes can also be used with a garden hose. Available in an appealing gift package.



Order no. 2.640-786.0

Car cleaning kit – exterior

Kit for cleaning car bodywork. Rotary washing brush, soft washing brush, 10 detergent tablets, chamois-leather. Suitable for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class. Washing brushes can also be connected directly to a garden hose with the Kärcher garden hose adapter.



Order no. 2.850-472.0

Garden cleaning kit

Kit for cleaning around the house and garden, such as garden furniture or roller shutters. Kit consists of a Soft Washing brush, 10 detergent tablets and a water filter.



Order no. 2.850-475.0

K 4.86M

Brushes and cleaning sponges

Adapter for garden hose coupling

For connecting all Kärcher brushes and cleaning sponges to garden hoses with quick-action coupling system. Water flow control and water stop directly on the adapter.

Order no. 2.640-732.0



Replacement sponge for hard surface cleaning sponge

Simply pull off the old sponge and secure the new one to the cling strip fastener.

Order no. 2.640-735.0



Replacement sponge for universal cleaning sponge

Simply pull off the old sponge and secure the new one to the cling strip fastener.

Order no. 2.640-734.0



Hard-surface cleaning sponge

The cleaning sponge excels through a soft, water-permeable sponge which dissolves and flushes away dirt. Cling strip fastener for easy replacement, good detergent absorption and distribution. Working width of 248 mm for good area coverage, all-round protector ring protects surfaces from scratches, a union nut guarantees secure mounting to the trigger gun, integral rubber pad removes stubborn soiling, e.g. insects, and an ergonomically shaped handle for convenient operation. Suitable for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class and for using it with the garden hose in conjunction with the adapter for garden hose connection.

Order no. 2.640-606.0



Universal cleaning sponge

The cleaning sponge excels through a soft, water-permeable sponge which dissolves and flushes away the dirt. A cling strip fastener provides for good detergent absorption and distribution. An all-round protector ring protects surfaces from scratches. A union nut guarantees secure mounting to the trigger gun. A rubber pad removes stubborn dirt, such as insects, an ergonomically shaped handle ensures easy and convenient handling. Suitable for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class and for using it with a garden hose in conjunction with an adapter for garden hose connection.

Order no. 2.640-607.0



Brushes and cleaning sponges

Rotary wash brush

For cleaning of all smooth surfaces like varnish, glass or plastic. Gentle-action rotating bristles, joint on handle infinitely adjustable through 190° for cleaning difficult-to-reach areas, infinitely adjustable speed and cleaning agent control, easily replaced bristle element, all-round protector ring protects surfaces from scratches, a union nut guarantees secure mounting to the trigger gun. Accessory for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class.



Order no. 2.640-907.0

Wheel washing brush

For highly effective 360° cleaning. Shape and all-round bristles make it particularly suitable for difficult-to-reach areas and small recesses, such as wheels and bicycle spokes. Special features of the brush are the uniform 360° water distribution for dissolving and flushing away the dirt, quality bristles for efficient and gentle-action cleaning, a union nut for secure mounting to the trigger gun and an ergonomically shaped handle for easy and comfortable handling.



Order no. 2.640-699.0

Soft surface brush

Particularly suitable for cleaning larger surfaces, such as cars, caravans, boats, conservatories, roller shutters. The brush features soft, gentle bristles, a working width of 248 mm for good area coverage, an all-round protector ring which protects the surface from scratches, a union nut for secure mounting to the trigger gun, a rubber pad for removing stubborn dirt, e.g. insects, and an ergonomically shaped handle for easy and comfortable handling.



Order no. 2.640-590.0

Universal soft brush

Suitable for cleaning all surfaces, such as garden furniture and glass. The brush features soft, gentle bristles, an all-round protector ring which protects the surface from scratches, a rubber pad for removing stubborn dirt e.g. insects, a union nut for secure mounting to the trigger gun and an ergonomically shaped handle for easy and comfortable handling.



Order no. 2.640-589.0

Hard surface cleaners

Delta-Racer D 150 Display

The Delta-Racer Display has a promotional header card and an attractive design, which should especially enhance impulse buying. It is also very suitable for promotional placement. The Delta-Racer Display consists of eight Delta-Racer D 150. Dimensions: Quarter-Pallet (600x400 mm)

Order no. 2.642-036.0



Hard surface cleaners

Delta-Racer D 150


Full Power. Gentle Pressure – the first wash brush with the power of high pressure. For splash free cleaning of sensitive surfaces like varnish of cars or motorbikes, glass, conservatories, garage doors, shutters, blinds, etc. Quick, efficient and effortless cleaning because of high pressure in conjunction with a brush. The efficient combination of a high pressure jet and a manual brush of the Delta-Racer saves energy, water and up to 30% of your time. Therefore the Delta-Racer cares for more cleanliness around the house and garden. Accessory for all Kärcher High Pressure Cleaners of the K2 - K7 class.



Order no. 2.641-812.0

T 400 Display

The T 400 Displays has a promotional header card and an attractive design, which should especially enhance impulse buying. It is also very suitable for promotional placement. The T 400 Display consists of six T-Racer T 400. Dimensions: Quarter-Pallet (600x400 mm)



Order no. 2.641-751.0

T 400 T-Racer

For the cleaning of surfaces such as wooden and stone patios, terraces and driveways without splashback. With additional power nozzle for efficient cleaning of corners and edges. Improved cleaning performance through simple changeover from T-Racer nozzles to power nozzle. Adapting to cleaning power by adjusting height. Further Kärcher accessories can be connected to the extension lances. Accessory for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class.



Order no. 2.641-647.0

PS 30 – Powerscrubber

Scrubber with 3 integrated high-pressure nozzles offers greatly enhanced cleaning performance compared to a standard scrubber. Removes even stubborn dirt quickly and effectively from all kinds of surfaces (especially for cleaning corners, steps, balconies and garages). Accessory for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class.



Order no. 2.640-865.0

T-Racer replacement nozzles

For simple replacement of T-Racer nozzles. Grey nozzles for K2 - K5 series.

Order no. 2.640-727.0



Hard surface cleaners

T 300 T-Racer

For the cleaning of surfaces such as wooden and stone patios, terraces and driveways without splashback. Equipped with assist handle for cleaning vertical surfaces, such as garage doors. Two rotating fan jet nozzles for increased cleaning power. Nozzle distance can be adjusted to vary height at which the T-Racer hovers. Adjustable hovercraft effect. Further Kärcher accessories can be connected to the extension lances. Accessory for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class.



Order no. 2.640-212.0

High-pressure hose extension - System up to 2007

High-pressure rubber hose extension, 10 m, K2-K8

Extends working radius of high-pressure hose. High-quality steel reinforced rubber hose. For pressures up to 160 bar and temperatures up to 80 °C. Connects between the machine and high-pressure hose. For Kärcher Consumer high-pressure Cleaners.



Order no. 6.390-096.0

High-pressure extension hose, 10 m, K2-K7

Extends working radius of high-pressure washer. Simply connect between trigger gun with quick-action connector clip and high-pressure hose- also suitable for pressure washers with high-pressure hose winder. Robust ID8 quality hose with textile braiding, anti-kink sleeve and brass connector for long life. Also suitable for use with detergents. For pressures up to 160 bar and temperatures up to 60 °C.



Order no. 6.390-961.0

High-pressure extension hose, 10 m, K2-K7

Extends working radius of high-pressure washer. Connects between machine and high-pressure hose. Robust ID 8 quality hose with textile braiding, anti-kink sleeve and brass connector for long life. Also suitable for use with detergents. For pressures up to 160 bar and temperatures up to 60 °C.



Order no. 6.389-092.0

High-pressure extension hose, 6 m, K2-K7

Extends the working radius of the high-pressure cleaner. Simply connect between the machine and high-pressure hose. Robust ID8 quality hose with textile braiding, anti-kink sleeve and brass connector for long life. Also suitable for use with detergents. For pressures up to 160 bar and temperatures up to 60 °C.



Order no. 6.390-243.0

K 4.86M

High-pressure replacement hose - System up to 2007

High-pressure replacement hose, 9 m

For older high-pressure cleaners on which the hose is permanently mounted to the trigger gun. The trigger gun has to be opened up to replace the hose. 9 m, 150 bar, up to 60 °C.

Order no. 6.389-555.0



High-pressure replacement hose, 9 m, K3-K7

For Kärcher Consumer high-pressure cleaners on which the hose is secured to the trigger gun with a quick-action connector-clip. 9 m, 160 bar, 60 °C.

Order no. 6.390-463.0



Miscellaneous

Accessories set quick connect

All Kärcher consumer high pressure washers from production date 1992 onwards can be upgraded with the accessory set „quick connect“. With the quick connect system the separation of the high pressure hose from the machine and the trigger gun is possible very quickly and easily. Does not fit to hose reel machines.

Order no. 2.641-828.0



Adapter B

For pressure washers with screw coupling up to 1989.

Order no. 4.762-062.0



Replacement fine mesh water filter

3 fine filter elements for replacing fine-mesh water filter installed in the pressure washer. Suitable for Kärcher pressure washers from 2002.

Order no. 4.730-108.0



Miscellaneous

Water filter

Prevents dirt particles in contaminated water getting into pump.

Order no. 4.730-059.0



Special applications

Foam nozzle 0,3 l

Accessory for Kärcher Consumer high pressure washers. With powerful foam for effortless cleaning of many surfaces like e. g. varnish of cars or motorbikes, glass, stone etc. Fill detergent directly into the foam nozzle, then stick the foam nozzle on the trigger gun and start cleaning. Accessory for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class. Ideal in conjunction with the Kärcher Ultra Foam Cleaner.

Order no. 2.641-848.0



Foam nozzle 0,6 l

Accessory for Kärcher Consumer high pressure washers. With powerful foam for effortless cleaning of many surfaces like e. g. varnish of cars or motorbikes, glass, stone etc. Fill detergent directly into the foam nozzle, then stick the foam nozzle on the trigger gun and start cleaning. Dosage of detergent can be controlled on the foam nozzle (yellow button), in addition the foam nozzle provides a pivotable spray level. Accessory for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class. Ideal in conjunction with the Kärcher Ultra Foam Cleaner.

Order no. 2.641-847.0



Kärcher Organiser

Convenient and clearly arranged stowage of Kärcher accessories. Consisting of 2 modules for flexible mounting options. The accessories are always ready to use and bristles and washing brushes are protected from bending.

Order no. 2.641-630.0



Replacement O-ring kit

For easy replacement of O-rings and safety pads at high-pressure washer accessories.

Order no. 2.640-729.0



Special applications

Sand-/wet-blasting kit

Used in conjunction with Kärcher abrasive for removing rust, paint and stubborn dirt. Accessory for all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class.

Order no. 2.638-792.0



Suction hose with non-return valve

For water intake from ponds, water butts, tanks for operation of pressure washer. No further water connection necessary.

Order no. 4.440-238.0



Pipe cleaning hose, 15 m

Clears blocked pipes and drains. Four backwards firing high pressure jets propel the hose into the pipe and clear the blockage. With consecutive marks and marker ring to show progress in the pipe. Flexible quality textile-braided hose for perfect results: with textile braiding, with extra short brass nozzle for maximum flexibility in the pipe, anti-kink sleeve and brass connector for long life. For indoor and outdoor use with all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class.

Order no. 2.637-767.0



Pipe cleaning hose, 7,5 m

Clears blocked pipes and drains. Four backwards firing high pressure jets propel the hose into the pipe and clear the blockage. With consecutive marks and marker ring to show progress in the pipe. Flexible quality textile-braided hose for perfect results: with textile braiding, with extra short brass nozzle for maximum flexibility in the pipe, anti-kink sleeve and brass connector for long life. For indoor and outdoor use with all Kärcher Consumer High Pressure Cleaners of the K2 - K7 class.

Order no. 2.637-729.0



Vario joint

Infinite adjustable vario joint to up to 180° for comfortable cleaning of difficult-to-reach areas. The vario joint is attached between trigger gun and accessory or between lance extension and accessory.

Order no. 2.640-733.0



Spray lances

Lance extension

Extends spray lance by 0.5 m. Applicable with all Kärcher accessories.

Order no. 4.760-262.0



3-step lance extension

Variable spray lance extension with 4 aluminium sections, extends to 90 cm, 1.30 m and 1.70 m.

Order no. 2.639-722.0



Angled spray lance

Extra long angled spray lance (approx. 1 m) for convenient cleaning of difficult-to-reach areas, e.g. roof gutters or car underbodies.

Order no. 2.638-817.0



Flexible spray lance

High and low-pressure jets. Spray lance flexibly swivels 180° to easily clean difficult-to-reach areas.

Order no. 4.760-272.0



Splash guard for dirt blaster

Reliable protects user from splashwater. Especially for cleaning of edges and corners. Pushes on to all Kärcher Dirt Blaster (except for 4.763-184).

Order no. 2.640-916.0



Triple Nozzle 3 Jet Spray Lance

3 jets in one – simply twist to select required jet. High-pressure fan jet – for efficient surface cleaning; High-pressure pencil jet - for precise detail cleaning; Low-pressure detergent jet – for applying detergent and cleaning delicate surfaces

Order no. 4.760-269.0



K4 high pressure washers

K 4.86M



makes a difference

Spray lances

Dirt Blaster, K2-K4

With rotary nozzle for stubborn dirt, e.g. moss-covered or weathered surfaces, and large area coverage. For Kärcher Consumer high-pressure cleaners.

Order no. 4.763-977.0



Vario Power spray lance, K3-K4

For infinitely variable pressure control from low-pressure detergent jet to high-pressure jet by simply twisting the spray lance.

Order no. 4.760-565.0

